


INSTALLATION GUIDE

Item Number: BU-CLR-SCO

DAINTE



1. Unbox all the items carefully.
2. Unscrew two side screws from the brass canopy.
3. Install the wiring to the wall, and attach the bracket to the electric box. (A)
4. Attach sconce to the bracket. (B)
5. Install screws from outside the canopy into the bracket. (C)